

Follow preheat and interpass instructions of the applicable Weld Technique Number (WTN). If the valve is installed during welding, mid-position valve if possible and follow Section G (Reduced Heat Input / Cooling Methods) of W91 / 191 Appendix A.