

Follow preheat and interpass instructions of the applicable Weld Technique Number (WTN). If the valve is installed during welding, mid-position valve if possible and follow the "Reduced Heat Input / Cooling Methods" section of W-91 Appendix A or W-93 Appendix A, as applicable. For mechanized welding, see Appendix B.