

This seawater service valve shall be disassembled prior to brazing to avoid damage to the valve internals. Valve internals shall be lubricated with A-A-50433 grease prior to reassembly (refer to CCPP-8005 & M42-18.3 for guidance). W-91 is Not Applicable.